



## Application Guide for Airelease Products



To be used in conjunction with the KPMF VWS Application Guide.

- As with the application of any self adhesive films, the surface must be cleaned thoroughly; all car wax and polish residues must be completely removed as failure to do this could affect the success of the application.
- On newly painted vehicles a minimum of one week must be allowed prior to the application of films.
- The Airelease technology allows ease of positioning and repositioning which must be completed at the time of application.
- Once positioned a squeegee should be used using light strokes with the pressure being increased gradually to remove all the air from under the film. If too much pressure is used this can cause the air channels to close which will diminish the effect of the Airelease technology.
- If bubbles are visible do not push the bubble from the outer edged with a squeegee as this may cause 'bruising'.
- If applying into recesses and using heat, this should be done immediately as a delay in heating can cause the film to lift. For extreme recesses it may be necessary to adopt the filleting process as outlined in the VWS Application Guide.